


# Banner Stand Instructions



- A. 2 - 36" Bottom Support Tubes
- B. 2 - 72" Upright Tubes
- C. 2 - T Connecters
- D. 2 - Parallel Clamps
- E. 6 - Rubber Crutch Tips
- F.1 - Allen Key

